



# SAN ANTONIO DRY STACK



**No Formliner  
Face Drawing Available**



**No Profile Drawing Available**

**General Information:**

The Styrene and ABS formliners are an economical solution for providing architectural pattern reproductions. The Styrene plastic formliner is a perfect alternative for single use applications which costs less than other liners. The ABS plastic formliner exhibits good impact resistance and excellent overall performance. Its reuse factor is 10, subject to pattern configuration, proper handling and jobsite configurations.

**Care and Handling:**

To protect from thermal deformation, formliners should not be exposed to temperatures above 140°F (60°C). To avoid discoloration from sunlight exposure, formliners should be covered with a tarpaulin when not in use. This helps prolong the life of the material and keeps the material clean.

Form Liners are subject to thermal expansion and contraction +/- 1/8" @ 70°F. Keep away from steam, acids, and certain fuels.

Styrene	ABS
<b>Product Code #</b>	<b>Product Code #</b>
<b>F70619</b>	<b>F70647</b>
<b>Uses</b>	<b>Uses</b>
<b>1</b>	<b>Up to 10</b>
<b>Material Thickness</b>	<b>Material Thickness</b>
<b>.090</b>	<b>.110</b>
<b>Standard Dimensions</b>	<b>Standard Dimensions</b>
<b>10' x 4'</b>	<b>10' x 4'</b>
<b>Color</b>	<b>Color</b>
<b>White</b>	<b>Gray</b>



No Photo Available