

## TECHNICAL DATA SHEET

### DESCRIPTION

The PCC Aztec® Castle Chair is an individual, plastic, bar support used to maintain the elevation of rebar in reinforced concrete. They consist of a cone shaped body, rebar saddles, and a wide base. PCC Aztec Castle Chairs are manufactured in the USA.

### APPLICATION

The PCC Aztec Castle Chair is used to support one layer of steel a required distance in elevation. It may be used to support steel on soft material form surface, such as carton forms or fill material.

### PRODUCT SPECIFICATION

- Cover height 1-1/2" to 6-1/4" in 1/4" increments
- Supports on average over 600 lbs. at room temperature



### FEATURES

- Dual Height Saddles
- Large On-Grade Foot
- Dark Recycled Plastic
- Made in the USA

### BENEFITS

- Withstands jobsite compressive loads without deforming
- Faster fulfillment times
- Contributes to LEED credits
- Less inventory with multiple heights in one

### HOW TO SPECIFY

Specific:

Rebar Supports shall be PCC Aztec® Castle Chair rebar supports manufactured by Dayton Superior Corp.

Generic:

The rebar supports shall meet building code requirements as required by \_\_\_\_\_ (insert name here). The rebar supports shall be plastic rebar supports manufactured in the USA.

### APPROVALS / COMPLIANCE

- CRSI
- Department of Transportation, DOT
- ACI-50-66
- ACI-315/ 315R
- LEED
- American Recovery and Reinvestment Act, ARRA
- Buy America/n Act

### INSTALLATION

1. Place PCC Aztec Castle Chair on base material orienting the appropriate height saddle with the rebar.
2. Place rebar on corresponding saddle.
3. Wire tie as needed with WTW Premium Tie Wire.

### RELATED PRODUCTS

- SB Slab Bolsters
- PC110 Rebar Impalement Safety Cap

### HOW TO ORDER

Specify: (1) quantity, (2) name, (3) cover height  
 Example: 500, PCC Aztec® Castle Chair, 4" cover

### ORDERING INFORMATION

Product Code	Description	Weight
122835	1-1/2" - 1-3/4"	0.0783 LB
121284	2" - 2-1/4"	0.0917 LB
122837	2-1/2" - 2-3/4"	0.1126 LB
121285	3" - 3-1/4"	0.1198 LB
122839	3-1/2" - 3-3/4"	0.1508 LB
122840	4" - 4-1/4"	0.19 LB
123562	4-1/2" - 4-3/4"	0.2 LB
123563	5" - 5-1/4"	0.219 LB
123564	5-1/2" - 5-3/4"	0.2316 LB
123565	6" - 6-1/4"	0.251 LB

### MANUFACTURER

Dayton Superior Corporation  
 1125 Byers Road  
 Miamisburg, OH 45342  
 Customer Service: 888-977-9600  
 Technical Services: 877-266-7732  
 Website: www.daytonsuperior.com

**TECHNICAL DATA SHEET****WARRANTY (ACCESSORIES)**

Limited Warranty. Dayton warrants, for a period of 60 days from the date of shipment (three years from the date of shipment in the case of formwork, excluding any consumable Products included with such formwork), that Products and any associated application drawings and engineering services provided by Dayton ("Ancillary Services") will be free from defects in material and workmanship and, in the case of custom designed formwork, that the formwork will meet the specifications set forth in the design drawings approved by Dayton and Customer. Any claim under this warranty must be made in writing within such warranty period. If any Product and/or Ancillary Service covered by a timely claim are found to be defective, Dayton will, within a reasonable time, make any necessary repairs or corrections or, at Dayton's option, replace the Product. Unless pre-authorized by Dayton in writing, Dayton will not accept any charges for correcting defects or accept the return of any Product. This warranty will not apply to any Products that have been subjected to misuse, neglect, storage damage, misapplication, accident or any other damage caused by any person other than Dayton, or that have not been maintained in accordance with Dayton's specifications. THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AS TO THE PRODUCTS AND ANCILLARY SERVICES. DAYTON MAKES NO OTHER WARRANTIES OR GUARANTEES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE. THE REMEDIES SET FORTH IN THIS SECTION ARE CUSTOMER'S EXCLUSIVE REMEDY FOR BREACH OF WARRANTY.