

TECHNICAL DATA SHEET

DESCRIPTION

A81 Jahn® "A" bracket is fabricated from high strength steel with a cad plated eccentric and painted body

APPLICATION

Can be utilized to hold a single horizontal wale or a single vertical stud with any type of wall form.



FEATURES

- Can be installed before or after the wales have been positioned
- When properly installed, bracket will not loosen from internal vibration of the concrete
- Uses 4-3/4" L&W snap ties
- Easy to install and strip, requires no nailing

INSTALLATION

1. Place the bracket on the snap tie end by slipping the tie end into the slots in the bracket body
2. Rotate the eccentric loosely over the tie end
3. Drop 2x4 waler in place
4. Slip the back slot in the bracket body over the tie directly behind the head
5. Push the bracket toward the plywood until the tie head emerges through the front of the bracket. Rotate the eccentric over the tie head and tighten

RELATED PRODUCTS

- A3 Snap Ties
- A44 Stainless Steel Snap Ties
- A82 Jahn® "C" Bracket

ORDERING INFORMATION

| Product Code | Description | Weight |
|--------------|-------------|----------|
| 143703 | | 1.412 LB |

MANUFACTURER

Dayton Superior Corporation
 1125 Byers Road
 Miamisburg, OH 45342
 Customer Service: 888-977-9600
 Technical Services: 877-266-7732
 Website: www.daytonsuperior.com

WARRANTY (ACCESSORIES)

Limited Warranty. Dayton warrants, for a period of 60 days from the date of shipment (three years from the date of shipment in the case of formwork, excluding any consumable Products included with such formwork), that Products and any associated application drawings and engineering services provided by Dayton ("Ancillary Services") will be free from defects in material and workmanship and, in the case of custom designed formwork, that the formwork will meet the specifications set forth in the design drawings approved by Dayton and Customer. Any claim under this warranty must be made in writing within such warranty period. If any Product and/or Ancillary Service covered by a timely claim are found to be defective, Dayton will, within a reasonable time, make any necessary repairs or corrections or, at Dayton's option, replace the Product. Unless pre-authorized by Dayton in writing, Dayton will not accept any charges for correcting defects or accept the return of any Product. This warranty will not apply to any Products that have been subjected to misuse, neglect, storage damage, misapplication, accident or any other damage caused by any person other than Dayton, or that have not been maintained in accordance with Dayton's specifications. THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AS TO THE PRODUCTS AND ANCILLARY SERVICES. DAYTON MAKES NO OTHER WARRANTIES OR GUARANTEES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE. THE REMEDIES SET FORTH IN THIS SECTION ARE CUSTOMER'S EXCLUSIVE REMEDY FOR BREACH OF WARRANTY.